

PLA33RX

Universal multifunction meter

User and service manual



version 0.4

Content

1 Introduction.....	3	7.1.5 PAS – password.....	11
2 Safety instructions.....	3	7.1.6 rES – factory setting.....	12
3 Front and rear panel.....	4	7.2 Menu P_2.....	12
4 Measured parameters.....	5	7.2.1 Communication interface RS485.....	12
5 Installation.....	5	7.3 P_3 Firmware version and energy counters reset.....	13
6 Connection.....	6	8 Normal monitoring mode.....	13
6.1 Supply voltage.....	7	8.1 Monitoring screens.....	14
6.2 Voltage measuring inputs.....	7	8.2 Max, Min and AVG values.....	16
6.3 Current measuring inputs.....	8	8.3 Optical signalization of inputs/outputs status.....	16
6.4 RS485.....	8	9 Power monitor software.....	16
6.5 Profibus.....	9	9.1 Device configuration.....	16
6.6 Network type.....	10	9.2 Date and time.....	16
7 Configuration.....	10	9.3 RS485 interface.....	17
7.1 P_1 General menu.....	11	9.4 Profibus.....	17
7.1.1 Utr – voltage measuring transformer.....	11	9.5 Inputs / outputs.....	17
7.1.2 Itr – current measuring transformer.....	11	9.6 Logging of measured parameters into SQL.....	19
7.1.3 System frequency.....	11	9.7 Tariff setting.....	19
7.1.4 Real-time clock.....	11	9.8 Modbus registers.....	20
		10 Technical features.....	21

1 Introduction

PLA33RX is an universal measuring instrument with high accuracy class, great sampling rate 25.6 kHz (50 Hz), various input / output combinations and other features. Instrument is designed for measuring of electrical parameters in low voltage and high voltage grids for 2, 3, 4 line and TN, TT grids.

PLA33RX can be as optionally equipped by 1GB Flash on-board memory to behave as a measured data logger with possibility of logged data download via RS485 interface.

Communication interface use Modbus RTU protocol and as an optional variant it is possible to have PLA33RX with Profibus communication interface.

Instrument is produced in following variants:


Device name	PLA33RX	C	M	D	R	A	P	Uxxx
RS485 communication interface								Auxiliary supply voltage
– without interface								U230 voltage 85 ... 265 V AC/DC
C with interface RS485								U60 voltage 24 ... 65 V AC/DC
Onboard flash memory								PROFIBUS communication interface
– without memory								– without interface
M with 1GB memory								P with Profibus interface
Digital inputs / outputs								Analogue output 4 ... 20 mA
– without digital I/O								– without output
D with digital I/O								A with analogue output
Relay outputs								
– without outputs								
R relay outputs								

2 Safety instructions










Instrument comply the standard EN 61010-1: Safety requirements for electrical equipment for measurement, control, and laboratory use.

- Installation of the instrument can be done by qualified and authorised person only.
- Instrument should not be installed in the environment with increased humidity and close to explosive gases.
- Use the instrument in accordance instructions written in the user manual.
- Before the disconnection of CT measuring circuits assure that terminals of CT are short circuited.
- Installation and connection changes can be done without supply voltage only.
- Do not apply supply voltage, measuring voltage and current higher that allowed.

3 Front and rear panel



Picture 1: Front panel

	– key for entering menu, parameters, avg, max / min values		– ESC key for cancelling or return
	– cursor key for moving up in menu and value increase		– cursor key for moving down in menu and value decrease
	– active recording into on board Flash memory	R1 R2 R3	– active relay outputs
K1 	– active digital outputs		– symbolize maximum values
	– symbolize minimum values of		– symbolize average values


4 Measured parameters

Universal multifunction meter PLA33RX is designed for measurement and monitoring of electrical parameters in 1 and 3 phase of LV and HV networks. Instrument architecture is based on fast 16 bits microprocessor which provides high computing power to assure the device being according the norm IEC 61000-4-30.

Parameter	L1	L2	L3	L1-L2	L2-L3	L3-L1	Σ L1-L3	Max	Min	AVG	Measuring range	Displayed range	Accuracy
Phase voltage	•	•	•					•	•	•	10 ... 600 V	0 ... 1 MV	±0.2 %
Line voltage				•	•	•		•	•	•	18 ... 1000 V	0 ... 1 MV	±0.2 %
Frequency	•							•	•	•	40 ... 70 Hz	40 ... 70 Hz	10 mHz
Current	•	•	•				•	•	•	•	0.01 ... 6 A	0 ... 1 MA	±0.2 %
cosφ	•	•	•					•	•	•	0.01 L ... 0.01 C	0.01L ... 0.01C	±1 %
Power factor	•	•	•					•	•	•	0.01 L ... 0.01 C	0.01L ... 0.01C	±1 %
THDU L-N	•	•	•					•	•	•	0 ... 999 %	0 ... 999 %	±5 %
THDU L-L				•	•	•		•	•	•	0 ... 999 %	0 ... 999 %	±5 %
Under and over deviation L	•	•	•					•	•	•			
Under and over deviation L-L	•	•	•					•	•	•			
Voltage unbalance u2, u0								•	•	•			
THDI	•	•	•					•	•	•	0 ... 999 %	0 ... 999 %	±5 %
TDD	•	•	•					•	•	•	0 ... 999 %	0 ... 999 %	±5 %
Voltage harm. (up to 40 th)	•	•	•								0 ... 999 %	0 ... 999 %	cl. 1
Current harm. (up to 40 th)	•	•	•								0 ... 999 %	0 ... 999 %	cl. 1
Voltage, current asymmetry								•	•	•	0 ... 100 %	0 ... 100 %	0.3 %
K-factor	•	•	•										
Current unbalance i2, i0								•	•	•	0 ... 99.9 %	0 ... 99.9 %	cl. 1
Active power	•	•	•				•	•	•	•	0 ... 15.3 kW	0 ... 999 MW	±0.4 %
Reactive power	•	•	•				•	•	•	•	0 ... 15.3 kvar	0 ... 999 Mvar	±0.4 %
Apparent power	•	•	•				•	•	•	•	0 ... 15.3 kVA	0 ... 999 MVA	±0.4 %
Distortion power	•	•	•				•	•	•	•			±0.5 %
Active energy +/-	•	•	•				•				0 ... 999 GWh	0 ... 999 GVh	cl. 0.5
Reactive ind. energy +/-	•	•	•				•				0 ... 999 Gvarh	0 ... 999 Gvarh	cl. 2
Reactive cap. energy +/-	•	•	•				•				0 ... 999 Gvarh	0 ... 999 Gvarh	cl. 2
Temperature											-40 ... +125°C		1°C

5 Installation

PLA33RX is prepared for wall mounting in the fixed switch boards. In order to assure well ventilation, instrument has to be installed vertically. Instrument is fixed into switchboard wall by two clips that are placed on the device at the bottom and top.




Picture 2: Dimensions

In order to assure well ventilation, instrument has to be installed vertically. There has to be empty space at least 50 mm at the top and bottom and 20 mm at the sides.

6 Connection

Value and type of auxiliary supply voltage has to be in accordance with rear device label. Standard auxiliary supply voltage is 85 .. 265 VAC. There is also a variant with 24 .. 65 DC/AC auxiliary supply voltage. Supply units are designed for system frequency 50Hz or 60Hz. Measuring inputs should be connected via sufficient protection like for example fuses or CB (2 – 10 A) place close to the instrument for easy maintenance. Measuring inputs of current has to be connected indirectly via measuring transformers with ration xx/5A or xx/1A.



Picture 3: Device connection at TN-C network

6.1 Supply voltage

Supply voltage is required to operate the PLA33RX. The type and level of the necessary supply voltage is written on the back label. Before applying the supply voltage, make sure that the voltage level and system frequency match the details on the label. The connection cables for the supply voltage has to be connected using a fuse. Use a fuse (6 A type C).

6.2 Voltage measuring inputs

Instrument has four voltage measuring inputs with input impedance 4 MΩ suitable for measurement according the category CATIII 600 V.

Each voltage measuring input have to be connected via circuit breaker or switch and fuse (10 A characteristic C) which are placed close to the device.



Notice

PLA33RX is not designed for measuring of DC voltage!

PLA33RX is not designed for usage in SELV grids!



Notice

If the voltage measuring inputs are connected over the voltage measuring transformers the power of measuring transformer power must be at appropriate level. Voltage measuring inputs have 5 mW self consumption. Recommendation from measuring transformer producers is to have loaded voltage measuring transformer on 70% of maximum power for the best accuracy.

6.3 Current measuring inputs

Instrument has three current measuring inputs for indirect measurement via current measuring transformers, either $\dots/5A$ or $\dots/1A$ ratio. CT ratio is freely adjustable from an instrument or via PC software.



Warning


Current inputs maximum permanent capability is 10 A.

Important

Before opening the current circuit be sure that measuring terminals of current transformer are connected together.

6.4 RS485

The PLA33RX has built-in one RS485 interface supporting Modbus RTU protocol. Connection of the RS485 bus to the device is on the separate terminal by two wires A and B. Shielding is not required.




Note

PLA33RX does not have built-in termination resistor. If the instrument is at the end of the RS485 bus it should be terminated by 120 Ω resistor.

RS485 interface is fully galvanic insulated from the supply circuits and measuring circuits.


6.5 Profibus

On the request the device can be prepared in variant with interface PROFIBUS version DP0.



6.6 Network type

PLA33RX is designed for various connections according to the grid type or measurement needs. Network settings defines the types network system in which the instrument is connected. In the following table are shown all possible connection variants that can be defined in the device menu.



7 Configuration

Before usage of the PLA33RX instrument it is necessary set several parameters essential for correct operation of the instrument in the different type of installations.

PLA33RX device can be configured from panel screen for most of the essential parameters. Configuration menu is divided to the two sub-menus for device fundamental settings and menu for communication interfaces settings. Enter the configuration menu by pressing the button **SET** for at least 5 seconds.

For moving in the menu use cursor keys **▲** and **▼**. Key **▲** is normally used for circle moving in the menu. Parameters setting is activated by pressing the key **SET**. Changing the parameter setting is done by cursor keys **▲** and **▼**, confirmation of newly set parameter value by key **SET**. Key **ESC** cancels setting or move back to higher menu or back to normal operation.

Most of the device parameter and functions can be enabled and configured only by PC and software PMS.

Parameter	Description
P_1	Main configuration menu
P_2	Communication interface configuration
P_3	Information about firmware version, energy counter reset

7.1 P_1 General menu

In the general menu **P_1** gather fundamental settings of an instrument. Table beneath shows all available parameters with factory setting and possible setting range. In order to move in between particular parameters the cursor button **▲** is used. Editing and storing the parameter is activated by button **SET**. Modification of parameter is done by buttons **▲▼**. Pressing button **ESC** returns to level back or cancel setting in case it was not saved by button **SET**.

Parameter	Description	Factory setting	Setting range
bcl	Display back-light brightness	ON	ON, OFF, 20 - 100%
Utr	primary / secondary voltage (transformer ratio of U)	230 / 230	1...750000
Itr	primary / secondary current (transformer ratio of I)	5 / 5	1...10000
Fr	Grid nominal frequency	50 Hz	50 or 60 Hz
Y--	Year setting	09	09 ... 99
M--	Month setting	01	01 ... 12
D--	Date setting	01	01 ... 31
h--	Hour setting	00	00 ... 23
M--	Minute setting	00	00 ... 59
PAS	Password	OFF	3 digits
rES	Reset to factory setting		

7.1.1 Utr – voltage measuring transformer

If voltage measuring transformers are used then it is important set primary voltage and secondary voltage of used transformer. If there is no voltage transformer used then factory setting can remain.

7.1.2 Itr – current measuring transformer

Instrument is designed for indirect current measurement. For correct function it is important set primary and secondary current of used CT.

Notice

Measuring input for current is sensing current in range 10 mA till 6 A. Maximum current transformer ratio is 7500 / 5 A.


7.1.3 System frequency

PLA33RX is designed for measurement in grids with 50Hz or 60 Hz system frequency. If the system is 60 Hz frequency it is important to set for correct measurement.

7.1.4 Real-time clock

Versions of PLA33RX with communication interface are equipped by internal real time clock and calendar. Setting of the time and date is available in configuration menu by editing parameters visible on the two screens.

Moving cursor on the parameter by key **▼** and pressing **SET** enters the setting. First screen in order is date setting (Year / Month / Day) and after pressing the key **▲** the second screen of time setting (Hour / Minute) will appear.



7.1.5 PAS – password

Device is possible to be protected against unauthorized configuration changes by three digit password. Entering the parameter PAS and activating the password setting by key **SET** opens definition of the first number of password. By key **▲** number is

defined while key ▼ moves cursor to another digit. Password is confirmed by key SET. Erasing the password is possible by setting the 000.

7.1.6 rES – factory setting

In case of need it is possible return PLA33RX back to factory setting. In the second configuration menu **P_2** there is a parameter **rES**. Activating that parameter by button **SET** device turns back tot factory setting including the real time clock.

7.2 Menu P_2

Second configuration menu related to the communication interface RS485 setting.

Parameter	Description	Factory setting	Setting range
Id	Unique identification number in RS485 network	0	0 ... 255
bd	Communication speed of RS485 interface	9.6 kBd	9.6 / 19.2 / 38.4 / 57.6 / 115 kBd
PAr	RS485 interface parity	---	--- (none), _o_ (odd), _E_ (even)
St	Stop-bit	1	1 / 2

7.2.1 Communication interface RS485

Instrument can have communication interface RS485 for connection into PC or another device.

- Id – unique number that identifies instrument in the RS485 network
- bd – communication speed between PLA33RX and converter (PC)
- Par – communication control via parity, that is as default inactive
- St – number of stop bit

Notice

Communication configuration of the device and convert, PC or other device has to be the same on both sides.

7.3 P_3 Firmware version and energy counters reset

In the menu P_3 are information about firmware version, parameter **FIr** and hardware version - parameter **VEr**.

In this menu it is also possible reset all energy counters. By buttons ▲ and ▼ set particular tariff. Press and hold button SET which will reset the energy counter.


8 Normal monitoring mode


After supply voltage connection is the instrument in normal monitoring mode when measure and show electrical parameters. Measured parameters are logically sorted and displayed in the group of particular screens.

8.1 Monitoring screens

Meaning of each screen is easily identified by usage of standard ISO symbols and value parameters. Every displayed parameter value is shown with its variable.

From any of screens press of button **ESC** returns to the first screen displaying phase voltage.





8.2 Max, Min and AVG values

For some of measured parameters the max and min values are stored. For displaying the maximum of measured value press shortly button **SET**. Max values are introduced by symbol ▲ before displayed value. Second press of button **SET** will show min value. Min values are introduced by symbol ▼ before displayed value. Third press of button **SET** shows average value of measured parameter introduced by ▲▼.

8.3 Optical signalization of inputs/outputs status

Digital inputs and outputs can be in four operating states. Signalization is mutual for all digital I/O and it is described in the table beneath.

Parameter	Description	Active	Inactive
In	input	K1●	K1○
Out	output	K1●	K1○
PuL	Pulse output	K1● pulse	K1○
AL	Alarm output	K1● flashing	

Relay outputs statuses are signalized by underline beneath the relay symbols **R1**, **R2**, **R3** in the upper right corner of display.


9 Power monitor software

PLA33RX allows fundamental configuration via keys on the the device. Full configuration is available via Power Monitoring Software only.

9.1 Device configuration


In the device configuration it is possible set following configuration:

- Type of instrument connection to the grid
- Nominal voltage, nominal current, system frequency
- Voltage and current measuring transformers ratio
- Averaging period of measured values and energy counter load profile interval.




9.2 Date and time

PLA33RX real time internal clock can be either set on the instrument or via software manually or synchronized with PC time.




9.3 RS485 interface

Device is equipped by communication interface RS485 with Modbus RTU protocol and all related parameters can be set via PMS SW too. Nevertheless it is recommended to set parameters manually on device to avoid possible ost communication after parameter changes.



9.4 Profibus

Special variant of PLA33RXCP with Profibus interface adds new cart that allows definition of Profibus address mapping.



Name	Phase	Data type	Scale	Start index
Profile 1				
Celkový 3F činný výkon	1	Float (4B)	1	0
Celkový 3F zdánlivý výkon	1	Float (4B)	1	4
Celkový 3F power faktor	1	Float (4B)	1	8
Frekvence	1	Float (4B)	1	12
Fázové napětí 20 ms	1	Float (4B)	1	16
Sdružené napětí 20 ms	1	Float (4B)	1	20
Činný výkon	1	Float (4B)	1	24
Cosφ	1	Float (4B)	1	28


9.5 Inputs / outputs

Instrument can be according to the variant (CDR, CMDR, CDRA, CMDRA) equipped by 4 digital fully programmable inputs / outputs, 3 relay outputs 3A/250VAC. PLA33RX can also have analogue output 4 – 20 mA.

Main parameters	Date and time	Communication	Inputs/Outputs	Alarms	Display settings	Data storage	Tariff settings	Commands
<div> <div> <h3>Outputs</h3> <div> <h4>R1</h4> Channel type: Alarm_out Inverted: <input type="checkbox"/> Currently: On = Switched on, Off = Switched off </div> <div> <h4>R2</h4> Channel type: Alarm_out Inverted: <input type="checkbox"/> Currently: On = Switched on, Off = Switched off </div> <div> <h4>R3</h4> Channel type: Digi_out Control: RS485 After start: Off Digi out: Off Inverted: <input type="checkbox"/> Currently: On = Switched on, Off = Switched off </div> </div> <div> <h3>Inputs/Outputs</h3> <div> <h4>K1</h4> Channel type: Digi_out Control: RS485 After start: Off Digi out: Off Inverted: <input type="checkbox"/> Currently: On = Switched on, Off = Switched off </div> <div> <h4>K2</h4> Channel type: Digi_out Control: RS485 After start: Off Digi out: Off Inverted: <input type="checkbox"/> Currently: On = Switched on, Off = Switched off </div> <div> <h4>K3</h4> Channel type: Digi_out Control: RS485 After start: Off Digi out: Off Inverted: <input type="checkbox"/> Currently: On = Switched on, Off = Switched off </div> </div> </div>								

Inputs / outputs can be controlled by simple logic comparators or it is possible define advanced rules. Function of inputs / outputs is defined in graphical tool under Power Monitoring SW at instrument configuration as light PLC.

Thanks to this programmable light PLC can be defined functionality like for example current monitoring relay or more complex three level protection for photo-voltaic power plants.




9.6 Logging of measured parameters into SQL

Power Monitoring Software allows log selected measured parameters from PLA33RX into SQL database. Among average value of selected parameter it is also possible record min and max values of the defined averaging period.

Averaging period for the Average value is defined in the Main parameters by Averaging period. Time window length of resetting of min and max values is defined at the same place.

It is possible read also min and max values of measured parameters. Define the interval window of min and max value wisely with consideration of SQL database file size.



The screenshot shows the 'Main parameters' tab in the Power Monitoring Software. The 'Profile' section is active, displaying a list of parameters to be logged. The 'Save Min/Max' checkbox is checked. The 'Hour' is set to 0, 'Minute' to 1, and 'Second' to 0. The parameters listed include Voltage (Phase voltage, Line voltage, Phase THDU, Line THDU), Current (Current, THDI), Cosφ (Cosφ, Total 3ph cosφ), Power factor (Power factor, Total 3ph power factor), Frequency, Power (Apparent power, Active power, Reactive power, Total 3ph active power, Total 3ph apparent power, Total 3ph reactive power), Deviation (Phase underdeviation, Phase overdeviation, Line underdeviation, Line overdeviation), Unbalance (Voltage unbalance u2, Current unbalance i2, Voltage unbalance u0, Current unbalance i0), K factor, Distortion power, Temperature, Angle (Voltage angle, Current angle), TDD, and Line voltage harmonic (Phase voltage harmonic, Phase voltage harmonic percents, Current harmonic, Current harmonic percents, Line voltage harmonic, Line voltage harmonic percents).

9.7 Tariff setting

Instrument energy counters are using four tariffs that can be operated either by signal on I/O input or according to the time program.

Main parameters
Date and time
Communication
Inputs/Outputs
Alarms
Display settings
Data storage
Tariff settings

Tariff settings

Tariff control:
Nothing

Time program

Program 1

Tariff ID:
1

Time:
00:00

+
-

Program 2

Tariff ID:
1

Time:
00:00

+
-

Program 1
Program 2

Monday
☒
☐

Tuesday
☒
☐

Wednesday
☒
☐

Thursday
☒
☐

Friday
☒
☐

Saturday
☒
☐

Sunday
☒
☐

9.8 Modbus registers

Complete description of Modbus registers and implementation of PLA33RX into any software is available on the request on export@bmr-trading.com.

10 Technical features

Parameter	Values
Supply voltage for variants PLA33RXU230 / PLA33RXU60	85 ... 265 VAC, 24 ... 65 V AC/DC
System frequency	50Hz or 60Hz
Current measuring range	0.01 ... 8 A (max permanent current 10 A)
Voltage measuring range L - N	0 ... 600 VAC
Power consumption	1.5 VA
Sampling frequency 50/60Hz	25.60 kHz / 30.72 kHz
Number of inputs / outputs	3 x relay outputs, 4 x digital I/O, 1 x 4 ... 20mA
Type of digital outputs	open collector, optically-isolated (S0)
Max voltage of digital output	24 VDC
Max current load of digital output	100 mA
Type of input	optically-isolated
Max voltage of digital input	24 VDC
Max input consumption	10 mA
Max pulse output frequency	10 Hz
Impulse length	50 ms
Impulse weight	1 ... 50 Wh (VArh)
Relay output max power	3A / 250 VAC
Primary voltage measuring transformer ratio	1 ... 750000
Primary current measuring transformer ratio	1 ... 10000
Maxium number of registered auxiliary supply power cuts	20
Data memory for measured parameters recording (optional)	1 GB
Communication port	RS485 insulated
Communication protocol	MODBUS RTU, PROFIBUS
Communication speed	9.6 / 19.2 / 38.4 / 57.6 / 115 kBd
Over-voltage class	300V CAT III
Pollution degree	2
Panel cut-out dimensions	92 mm x 92 mm
Site depth	90 mm
Dimensions	90 x 90 x 67mm refer to picture 2
Weight	525 g
Protection degree	IP20 rear panel / IP54 front panel
Related standards: EN 61010-1, EN 62586-1, EN 61000-6-2, EN 61000-6-3	